


SANGEAN SR-35CL

GB Operating Instructions MW/FM 2-band radio
E Instrucciones de manejo Radio de 2 bandas MW/FM



Controls

1. Volume On/Off control
2. Power indicator
3. Tuning LED indicator
4. Tuning scale
5. Tuning control
6. Boss for hand strap
7. Headphone socket
8. Waveband switch
9. Battery compartment

Power supply

To insert the battery, first open the battery cover by sliding it in the direction shown by the arrow. Insert two AA (LR6) size batteries into the compartment.

Headphone

Plug the headphone into the headphone socket for private listening.

Volume On/Off control

Turn on the power by switching the Volume On/Off control switch. Adjust it to the desired level of sound. Rotating the control clockwise will increase the sound level.

Waveband switch

Set the waveband switch to the desired waveband.

Tuning control

Slowly rotate the tuning control to select the required station. The tuning indicator will light when the station is correctly tuned.

Tuning scale

Rotate the tuning control until the tuning scale corresponds to the frequency of the required station.

General maintenance

Do not allow this unit to be exposed to water, steam or sand. Do not leave the unit where excessive heat could damage such as in a parked car where the heat from the sun can build up even though the outside temperature may not seem too high.

Specifications

Battery	2 X AA (UM-3/LR6) size
Frequency coverage	FM 87.5 – 108 MHz AM 520 – 1710 kHz
Output Power	120 mW 8 ohm
Headphone socket	3.5mm dia. (mono)

Controles

1. Control Volume On/Off
2. Indicador Power
3. Indicador LED Tuning
4. Dial Tuning
5. Control Tuning
6. Aro para correa de mano
7. Toma para auriculares
8. Interruptor Waveband
9. Compartimiento de baterías

Suministro eléctrico

Para insertar la batería, primero abra la tapa de baterías deslizándola en la dirección mostrada por la flecha. Inserte dos baterías tamaño AA (LR6) en el compartimiento.

Auriculares

Enchufe los auriculares en la toma para auriculares para oír en privado.

Control Volume On/Off

Encienda el aparato con el interruptor Volume On/Off. Ajústelo al nivel deseado de audio. Girar el control en el sentido de las agujas del reloj aumentará el nivel del audio.

Interruptor Waveband

Mueva el interruptor Waveband a la banda deseada.

Control Tuning

Gire el control Tuning lentamente para seleccionar la estación deseada. El indicador Tuning se iluminará cuando la estación esté correctamente sintonizada.

Dial Tuning

Gire el control Tuning hasta que el dial Tuning esté en la frecuencia de la estación requerida.

Mantenimiento general

No permita que esta unidad se exponga a agua, vapor o arena. No deje la unidad en un lugar donde pueda ser dañada por calor excesivo, como en un coche aparcado donde el calor del sol puede acumularse a pesar de que la temperatura exterior no parezca estar demasiado alta.

Especificaciones

Batería	2 X tamaño AA (UM-3/LR6)
Gama de frecuencias	FM 87.5 – 108 MHz AM 520 – 1710 kHz
Potencia de salida	120 mW 8 ohmios
Toma para auriculares	3.5 mm de diá. (mono)